


DIY Wooden Book Nook-YM03

蝴蝶收藏室

Butterfly Collection Room



Ages 14+

安全警告

- 为了保障您在娱乐时的安全，请在拼装之前阅读说明书。
- 此产品适合 14 周岁及以上的人群，儿童需在父母的指导下组装。
- 在未经授权的情况下擅自改变和修改本产品，将损害您在有关本产品的权益。

Safety warning

- To keep your safety, please read this manual before you start.
- This product is suitable for people over 14 years old, children must assemble under the guidance of their parents.
- Any unauthorized alteration or modification of this product will damage your rights and interests related to this product.

注意事项

- 小心地从板上取下配件，防止零件断裂。断点可以用磨砂棒磨平。
- 不要一次性将木板零件全部拆下来。产品需配合无毒环保胶水组装，胶水黏贴后需静置 2 小时达到最强固化，黏贴后请勿随意挪动。建议先进行黏贴部件后再组装其他接插件以节省等待时间。
- 本产品接插口的松紧程度是由加工工艺、环境温湿度决定。插接部位如果安装过紧，则需用磨砂棒将接口部位打磨再组装，如果安装过松，则需在组装后加胶水进行固定。
- 儿童在组装时需要成人陪同。
- 说明书上含有重要信息，请予以保留。

Attentions

- Carefully remove the accessories from the board, prevent parts from breaking. The break point can be smoothed with a frosting rod.
- Do not detach all the parts at the same time. Glue needs to be used at some points. After the glue is pasted, leave the product untouched for two hours to ensure a firm paste. To save time, you can do the pasting step first and then assemble the rest of plugins.
- The tightness of the connector is determined by the processing technology and the temperature and humidity of the environment. If the splicing part is too tight to be installed, you can polish it with a frosting rod before assembling it. If the installation is too loose, you can add some glue to fix it after assembly.
- Children need to be accompanied by adults when assembling.
- Please keep this instruction manual for future reference.

维护和保养

- 请勿将此产品靠近热源或浸入水中。并使用干净柔软的布清洁此产品。
- 请勿使用擦窗剂、喷雾剂、溶剂、酒精、氨水、研磨剂等化学清洁剂来清洁产品。
- 若在拼装过程中过，零件损坏或丢失、或遇到任何拼装疑问，请与客服联系。



Maintenance

- Do not place the product near heat or in water. And use a clean soft cloth to clean the product.
- Do not use the chemical cleaners to clean the product, such as window cleaners, sprays, solvents, alcohol, ammonia, abrasive and so on.
- Do not hesitate to contact us if you have any issues with the product.




电池盒测试

- 如图，将 LED 灯的端口连接到电池盒的端口，插入两节 7 号电池，打开开关，测试灯（6 个暖白灯）是否亮起。



Battery box testing

- Connect the port of the LED light to the port of the battery box as shown, and insert two AAA batteries. Turn on the switch and test whether the lights (6 white lights) are on.




配件 Accessories



电池盒 *1
Battery box*1



触摸线 *1
Touch line*1



LED 灯 *1
LED light set*1



磨砂棒 *1
Frosted rod*1



镊子 *1
Tweezers*1




防尘罩 1*1
Dust cover 1*1



防尘罩 2*1
Dust cover 2*1



胶水 *1
Glue*1



贴纸 *1
Sticker*1



纸配件 1-2*1
paper 1-2*1



纸配件 3-4*1
paper 3-4*1



纸配件 5*1
paper 5*1















镜子 *1
Mirror*1



宝珠 *1
Bead*1



板材清单 Wood block list



STEP 1

制作 37 本大书。

Make 37 big books.

Paper 1-1

M38



+



STEP 2

制作 15 本小书。

Make 15 small books.

Paper 1-2

M40



+



STEP 3

制作 3 本立体书。

Make 3 folding books.



Paper 3



+

Paper 1-1



STEP 4

制作 9 个卷轴。


Make 9 scrolls.

沿着纸的长边卷


Roll along the longer side of the paper.




Paper 4



STEP 5



M41





+






Paper 2




STEP 6








STEP 8



STEP 9





M14


STEP 7




STEP 8





STEP 10




STEP 11



STEP 12




STEP 13




STEP 14



STEP 15






STEP 16




STEP 17








STEP 19



L12

Paper 5



油纸粘贴在 L12 背面。
Paste paper 5 on the back of L12.

STEP 20



L13

Paper 5




油纸粘贴在 L13 背面。
Paste paper 5 on the back of L13.

STEP 21

G11 插到 G9 底部，注意 G12 的印刷面朝向。

Insert G11 into the bottom of G9. Note that the printing side of G12 faces towards the bottom.




STEP 22

G20 插到 G27 底部。
Plug G20 into the bottom of G27.






STEP 23

G22 插到 G21 底部。
Plug G22 into the bottom of G21.




STEP 24





STEP 21




G13



STEP 4*3



STEP 22




G15



STEP 23






STEP 1*5



STEP 25












STEP 26




STEP 27



F28 较长一边在外。
F28 the longer side is out.





STEP 28





STEP 29






STEP 30

注意 F3 零件的正反面朝向。

Note the positive and negative orientation of F3 parts.





STEP 31

注意 F21、F27、F46、F47 零件的正反面朝向。

Note the front and back orientation of F21, F27, F46 and F47 parts.





STEP 32



STEP 33






STEP 34

油纸粘贴在 K1 背面。
Paste paper 5 on the back of K1.




油纸粘贴在 K1 背面。



Paste paper 5 on the back of K1.




STEP 35




STEP 36






STEP 1 * 4





STEP 35



A13

B5 A21 A20 A23 A22



M34




M23





M34 与 B1 不能
使用胶水粘贴。
M34 and B1
cannot be
pasted with
glue.



M36






M35



STEP 37

粘贴时不要超过此线

Do not go beyond this line when pasting




A9



A3

A9 与 A7 不能使用胶水粘贴。

A9 and A7 cannot be pasted with glue.



C 板 (Wood board C)



A8




A2 与 A8 不能使用胶水粘贴。
A2 and A8 cannot be pasted with glue.

镜子
Mirror



H10



STEP 38

H22



H31



H9



D 板 (Wood board D)


STEP 39



J1




Paper 2




H27

H50



H44

H46




H5



H1




H26




H42

H43




H40


H41







H38




H39




















利用组件将
灯线卡紧。
Use the
assembly to
fasten the
lamp line.









按照图示将 28cm 与 30cm 灯线排列。

Arrange the 28cm and 30cm light lines according to the figure.



按照图示先将 30cm 灯线穿过 M42 尾部的凹槽，再将灯线与 M42 一起穿过 K26 的孔。

First pass the 30cm light line through the groove at the end of M42 as shown, and then pass the light line and M42 through the hole above K26.



将灯珠头弯折成 90 度。

Bend the bead head to 90 degrees.

按照图示将 28cm 与 30cm 灯线排列。

Arrange the 28cm and 30cm light lines according to the figure.



STEP 37

触控开关 (Switch chip)



F38


STEP 38



A1



A26



防尘罩 2
Dust cover 2

撕掉表面保护膜。
Remove the surface protective film.



将触控开关粘贴在圆形图案背面。
Paste the touch switch on the back of the circular pattern.



插入防尘罩 1 前撕掉表面保护膜。
Remove the surface protective film before inserting the dust cover 1.

拼装完成，在电池盒中放入两节 7 号电池，按下触控开关即可亮灯。

After the assembly is completed, put two No. 7 batteries in the battery box and press the touch switch to turn on the light.



Butterfly Collection Room
